

## Assembly guide for Albany 426 Log Store

RECOMMENDED TOOLS: HAMMER, POZIDRIVE SCREWDRIVER (BATTERY OPERATED IS USEFUL), STANLEY KNIFE, PROTECTIVE GLOVES.

ESTIMATED ASSEMBLY TIME: TWO PEOPLE, 1-2 HOURS.

WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST

<b>PARTS LIST</b>	<b>D: 1 x roof</b>
<b>A: 1 x floor</b>	<b>E: nail &amp; screw pack</b>
<b>B: 1 x back</b>	<b>F: 1 x felt</b>
<b>C: 2 x ends</b>	<b>G: 2 x fascia boards</b>

1. Treat the underside of the floor if the building has been supplied untreated. Lay the floor panel (A) in its desired position (remember to leave enough space around the building for roof overhang and maintenance). It is essential the floor is on a solid, level base, otherwise the building will not fit together properly and the door may not fit flush. Place the panels around the floor - it will help you understand how they fit together.

2. Position the back section (B) on the back edge of the floor (the lip on the bottom overhangs the floor). While your assistant holds the back, place an end panel (C) on the floor to form a corner. Making sure the panels are sitting flat on the floor and are butted together, screw through the end section into the back from the inside using two of the screws provided.

3. Select the second end (C) and place it on the floor opposite the other one. Screw to the back panel as before with two screws, again making sure the sections are flat on the floor.

4. Place the roof section (D) on top of the other panels, which should sit inside the framing of the roof. Before the next step, check that the roof is square and sitting flat on the sides - if not it is possible the floor is not level and will need packing in one corner.

5. With the roof square, check that the three walls are sitting flat on the floor. Screw the panels to the floor using two screws per panel, ensuring that you screw into a floor joist (follow the lines of nails in the floor to locate the joists).

6. Fix the roof panel into the top of the side panels using the 40mm nails.

7. Felt the roof using the small clout nails provided. Place the strip on the roof so it overhangs each side sufficiently. Crease over the front edge and secure to the front framing every 100 –150mm starting from the centre. Repeat at the back (making sure the felt is taut), then at the ends.

8. Nail the fascia boards (G) to the to the ends of the roof. Trim the felt if necessary.

If your building has been supplied untreated, it requires treating straight away.

We recommend you re-treat your building within 6 months and from then on annually.

Albany Brown treatment can be ordered from your local retailer in 5 litre tubs.

These instructions are meant as a guide only. We reserve the right to alter design without prior notice.

Thanks for buying an Albany shed. [www.albanysheds.co.uk](http://www.albanysheds.co.uk)

